

1. Down load "SmartRMS" from App store .




1) Run App store




2) Search "SmartRMS".

3) down load "SmartRMS".



4) Run SmartRMS.

2. How to use Smart RMS.




1) input IP Address.

2) set port number (Default – 9871)

3) input Username.

4) input Password .



It will convert the image from 2 CIF or D1 to CIF size for smart RMS. (recommended)




The image size will be transferred to Smart RMS.


3. Live viewer



Back to previous display .



Move to before channel.



Move to next channel.



PTZ control button


4. PTZ control on the Smart RMS.



Move to left.



Move to right.



Move to bottom.



Move to up .




Zoom -in .



Zoom out.

5. PlayBack .



Please input Year, Month, Day, Hour, Minute, Camera No etc..



Move to previous display .



Play back .

< play back screen >.



Back previous display.



Move to first frame per hour.



Move back 1 frame .



stop



Playback



Move foward 1 frame



Move to last frame per hour .